


# EMO SWING UNIT TO FIT A LOCK (WITH WITHOUT EXU-S1)



**NOTE:**  
RELAY CONTACT MUST BE  
RATED FOR THE CURRENT DRAWN  
BY THE LOCK(S) YOU INSTALL